

Rechargeable Lithium Battery

Operation and Maintenance manual RS-R51100A







Legal Provisions

This manual describes in detail the requirements and procedures for safe installation and operation of TOPBAND lithium battery pack. Please read this manual carefully, only qualified persons are allowed to install, operate and maintain the system, otherwise it may cause product damage or personal safety risks.

Any actions against safety operation, or do not follow rules of this manual and limited warranty letter, will void warranty and qualification of this product. Meanwhile, the manufacturer will be not responsible for the product damage, property damage, personal injury or even death.

The information contained in this manual is accurate when it's issued. TOPBAND reserve right to change specification (such as optimization, upgrade or other operations) without prior notice, please always view the latest document via QR code. In addition, please noted that the diagrams/schematics in this document are used to help understand system configuration and installation instructions, which may be different from the actual items at the installation.

Manual QR code



Register QR code



Legal Terms

TOPBAND will retain the copyright of this document, do not extract, copy or translate in any ways without the written permission.

Version record

Version	Issued date	Updated content	Author
V00		Draft version	Рор
V01		Released version	Рор
V02		Explain the DIP setting in detail	Рор



Content

1. Information	
1.1 Validity	4
1.2 Target Group	4
1.3 Levels of warning messages	4
1.4 Symbol Description	5
1.5 Abbreviation Description	5
2. Safety	7
2.1 Safety precautions	7
2.2 Safety instructions	7
2.2.1 Safety gear	7
2.2.2 Emergency safety measures	8
2.2.3 Other Tips	
3. Product Overview	
3.1 Introduction	9
3.2 Features	
3.3 Specification	
3.3.1 Dimension	
3.3.2 Parameters	
3.3.3 Panel Interface	
3.4 Protection function	
4 Installation	
4.1 Preparation	
4.1.1 Safety Compliance	
4.1.2 Environment	
4.1.3 Tools	
4.2 Inspection	
4.2.1 Unpacking	
4.2.2 Scope of delivery	
4.2.3 External cable kits	
4.2.4 Battery registration	
4.3 Start Installation	
4.3.1 Remainder	
4.3.2 Procedures	
4.3.3 Tips	
5. Cable connection and commissioning	
5.1 Get battery ready	
5.2 Grounding cable connection	
5.3 Communication cable connection	
5.4 DC power cable connection	
5.5 Connecting with inverter	
5.6 Commissioning	
5.7 Switch off battery	
6. Transport, Storage	
7. Disposal of battery	
Appendix I	



1. Information

1.1 Validity

This document is valid for: RS-R51100A Battery Pack.

1.2 Target Group

This document is intended for qualified persons and operators. Only qualified persons are allowed to perform the activities marked in this document with a warning symbol and the caption "Qualified person". Qualified persons must have the following skills:

- •Knowledge of how lithium iron phosphate batteries work and are operated.
- •Knowledge of how an energy storage system (including PV/battery/hybrid inverter, MPPT, Meter, Distribution box etc.) works and is operated.
- •Knowledge of local applicable connection requirements, standards, and directives.
- Training in the installation and commissioning of electrical devices, batteries.
- Training in how to deal with the dangers and risks associated with installing, repairing and using electrical devices, batteries.

1.3 Levels of warning messages

The following levels of warning messages may occur when handling the product



Indicates a hazardous situation which, if not avoided, will result in death or serious injury.

MWARNING

Indicates a hazardous situation which, if not avoided, could result in death or serious injury.

A CAUTION

Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury or product permanent damage.

A NOTICE

Indicates a situation which, if not avoided, can result in property damage or product not work or accelerated product damage



1.4 Symbol Description

1.4.1 Symbols on products label

Label	Definition	
4	Beware of electrical shock	
(A)	Do not place the battery within children/pet touchable area.	
	Do not place the battery near heat source and flammable material	
7	Do not expose the battery to direct sunlight, rain and snow.	
	Do not short circuit the battery	

Lable	Definition	
TÜVRheinland CERTIFIED	The certificate label for Safety by TÜV Rheinland	
RECOGNIZED COMPONENT COMPO	The UL1973 certificate label for Safety by Intertek	
CE	The certificate label for European EMC directives	
UK	The certificate label for U.K EMC directives	
	Recycle label	
	WEEE designation	

1.4.1 Other symbols

Label	Definition
▲ Qualified person	Indicates activities that can only be performed by qualified persons
	Grounding point

1.5 Abbreviation Description

Abbreviation	Definition	
Battery/battery	Single RS-R51100A rechargeable lithium iron phosphate battery pack including cells,	
pack/battery module	BMS and enclosure etc.	
Battery system/cluster	Multiple RS-R51100A battery pack connected in parallel with power, communication	
	and grounding cables and installation auxiliaries.	
BMS	Battery management system. Electronical Unit to ensure lithium cells' safety and	
	display information or control the battery work mode.	
SOC	State of charge. The battery state of charge refers to the percentage of the remaining	
	capacity and rated capacity of the battery.	



SOH	State of health. The battery health status refers to the percentage between the full	
	charged capacity and the rated capacity of the battery.	
DIP switch	Dual in-line package switch	
COCP	Charge over current protection	
DOCP	Discharge over current protection	
COVP	Cell over voltage protection	
POVP	Pack over voltage protection	
CHTP	Charge high temperature protection	
DHTP	Discharge high temperature protection	
CUVP	Cell under voltage protection	
PUVP	Pack under voltage protection	
CLTP	Charge high temperature protection	
DLTP	Discharge high temperature protection	
SCP	Short circuit protection	



2. Safety

2.1 Safety precautions



Explosion risk

- •Do not impact the battery with heavy objects.
- •Do not squeeze or pierce the battery pack.
- •Do not throw the battery pack into the fire.

A WARNING

Fire risk

- •Do not expose the battery pack to the condition over 80°C.
- •Do not put the battery near a heat source, such as a fireplace.
- •Do not expose the battery pack to direct sunlight or raining.

A CAUTION

Electric shock risk

- •Do not allow non-qualified person to disassemble the battery pack.
- •Do not touch the battery pack with wet hands.
- •Do not expose the battery pack to moisture or liquid environment.

A NOTICE

Damage risk

- •Do not short-circuit or reverse connect the battery.
- •Do not use chargers or charging devices unapproved by the manufacturer to charge the battery.
- •Do not mix batteries from different manufacturers or different kinds, types or brands.

2.2 Safety instructions

The battery has been designed and tested in accordance with international (such as UL, IEC, UN38.3 etc.) safety requirements. However, due to various factors during the whole lifetime process, TOPBAND cannot guarantee absolute safety, in order to prevent personal injury and property damage and ensure long-term operation of the battery, please do read the below section carefully to operate the battery and handle emergency situations.

2.2.1 Safety gear

It is required to wear the following safety gear when installing and handling the battery pack.







Safety Glasses

Safety Shoes

Insulated gloves

2.2.2 Emergency safety measures

Water invasion

Please cut off the AC power supply of the system first and then disconnect all switched under the premise of ensuring safety.

Electrolyte or gas leakage

If the battery pack leaks electrolyte, avoid contact with the leaking liquid or gas. If one is exposed to the leaked substance, immediately perform the actions described below.

- Gas Inhalation: Evacuate the people in the contaminated area and seek medical aid immediately.
- Eye Contact: Flush your eye with clean and flowing water for 15 min, and seek medical aid immediately.
- **Skin Contact:** Thoroughly rinse the exposed area with soap and water to be sure no chemical or soap is left on them, and seek medical aid immediately.
- Ingestion: Induce vomiting, and seek medical help immediately.

AWARNING

In case of fire situations, please use carbon dioxide fire extinguisher rather than liquid to put out fires.

2.2.3 Other Tips


- All the product are strictly inspected before shipment, please contact your supplier for replacement if you notice there's any defectives such as swelling.
- Do not disassemble batteries and components, otherwise the manufacturer will not be responsible for any damage caused by unauthorized disassembly or repair.
- Do enable the battery to be safely grounded before use to make sure the system in safe and normal operation.
- Please ensure that the electric parameters of these devices are compatible mutually before connecting the battery to other devices.
- Please take the environmental factors into careful considerations to ensure that the system can work in a suitable condition as the environment and storage methods have a certain impact on the service life and reliability of this product.



3. Product Overview

3.1 Introduction

The RS-R51100A battery is designed for residential application and works as a storage unit in the photovoltaic system. It is a 51.2V lithium battery system, with BMS inside. It could be operated in both on-grid, back-up and off-grid modes with compatible inverters. Below is the general schematic of an ac-coupled system with the batteries.



ACAUTION

This electrical connection in this diagram is only for illustration, please follow the Manual suggestions of related devices and operate in accordance with locally applicable connection requirements, standards, and directives.


3.2 Features


- •Highest safety, battery is made from LiFePO4 chemistry and comply with highest international safety and transport standard.
- Modular and flexible, support up to 32 batteries connect together to expand the system energy.
- •Build-in pre-charge circuit to avoid rush current when connecting with different inverter/chargers.
- •Automatic dynamic addressing function when connected multiple batteries together.
- •Support a maximum of 96% DOD under off-grid and back-up application.
- •Built in BMS provide warning and protection functions including over-discharged, over-charged, over-current, short-circuit and high/low temperature.
- •LiFePO4 as cathode material and automatic balancing function to meet longer cycle life.
- •Compact size and light weight for easy installation and maintenance.
- •Multiple installation bracket to adopt with different customers' requirement.
- •LED display, CAN/RS485 port for external communication and upgrade the BMS firmware.
- •Rapid shut down function for North American market.




3.3 Specification

3.3.1 Dimension







3.3.2 Parameters


Items	RS-R51100A		
Rated voltage	51.2V		
Max. voltage range	44.8~57.6V, Shipping voltage>5	51.2V	
Charge voltage	56.0V		
Float charge voltage	54.6V		
Nominal energy@0.2C	5.12KWh		
Usable energy@0.2C	4.92kWh		
Nominal capacity@0.2C	100Ah		
Dimension	482*133.5*460mm (18.9*5.2*18	482*133.5*460mm (18.9*5.2*18.1 inch)	
Weight	~46kg (101lb)		
Standard charge current	≤50A		
Max. charge current	70A		
Standard discharge current	≤50A		
Max. discharge current	100A (initial temp. ≤30°C)	100A (initial temp. ≤30 °C)	
Peak discharge current	101~119A@5mins 120~200A	@15S	
Communication	RS485 /CAN		
Max parallel number	32 pcs		
Operation temperature 1	Charge: -5~50℃		
	Discharge:-10~50°C		
Ctorono torono avatura	0°C <t<30°c< td=""><td><6 months</td></t<30°c<>	<6 months	
Storage temperature @off mode	-10°C <t<45°c< td=""><td><3 months</td></t<45°c<>	<3 months	
won mode	Recommended environment	15~35℃, 5~75%RH	



ANOTICE

The optimum operating temperature range is from 15°C to 30°C, Frequent exposure to the harsh temperatures may worsen the performance of the battery pack and cycle life.

3.3.3 Panel Interface



No.	Items	Usage description	Remark
Α	Handles	For handling, intallation and disasembly of battery	
В	Grounding	Used to connect battery with ground	
С	Positive terminal	Used to connect the inverter/charger	
D	Dry contact	1 channel input signal	
		2 channels output signal	
E	Reset	Used to reset BMS or sleep/awake BMS in power	
		on mode.	
F	M/S	Used to indicate the module is Master or Slave	Single mode:OFF
		battery	Parallel mode:
			ON- Master battery
			OFF-Slave battery
G	Link IN	For internal and external communication	
	Link OUT		
Н	DIP	Used to set the RS485 baud rate and inverter	
		protocol choosing	
- 1	RUN	Used to show battery is in running status when	
		lighting or flashing	
J	ALM	Used to show battery Alarm/Protection status	
K	soc	Used to show battery real-time SOC	
L	Power switch	Used to Power on/off battery	



М	Negtive terminal	Used to connect the inverter/charger	
N	Mounting ear	Used to fix with rack or cabinet	

3.3.3.1 D: Dry contact

PIN	Туре
1	NO Output1, Charge enable/disable signal
2	
3	NO Output2, discharge enable/disable signal
4	
5	Passive INPUT signal.
6	Rapid Shut Down function for US

3.3.3.2 G: Link IN / Link OUT

Port	Pin No.	Definition	Remarks
Link IN	1	RS485-B1	1.Used to connect with external
	2	RS485-A1	devices to establish
	3	SGND	communication.
	4	CAN-H	2.Used to connect with upper
	5	CAN-L	battery pack Link OUT.
	6	SGND	
	7	RS485-A1	
	8	RS485-B1	
Link OUT	1	RS485-B2	Used to connect with
	2	RS485-A2	downward battery pack Link IN.
	3	SGND	
	4	CAN-H	
	5	CAN-L	
	6	SGND	
	7	RS485-A2	
	8	RS485-B2	

3.3.3.3: DIP addressing

DIP						Remarks	
RS485 baud rate	Undefined			Protocol			
1	2	3	4	5	6	7	
ON: 115200	Reserved for multiple cluster			0	0	Protocol ID0	
OFF: 9600	parallel and other future function			1	0	Protocol ID1	
			0	1	Protocol ID2		
				1	1	reserved	
Keep all batteries	Keep default setting Master:			er: acc	ording to inverter brand		
the same setting	Slave: keep default setting				default setting		

Note:

Only master battery needs to set the Protocol ID, keep all slave battery default setting, after choose the protocol



ID, the battery will auto detect the inverter infomation and corresponding to get into running, restart to take effect after setting new DIP sequence.

Protocol ID	CANbus Connection	RS485 Connection	DIP setting (Master battery)
0	Victron/SMA/Studer Innotec/Sofar	Voltronic/RCT/MPP/Alph a outback/Phocos	ON 1 2 3 4 5 6 7 X000000
1	Sol-Ark/Solis/Goodwe/Deye/ Growatt/SAJ/LUXPOWER Megarevo/INVT/Sermatec/ TBB/MUST/Sunsynk		ON 1 2 3 4 5 6 7 X000010
2	Schneider		ON 1 2 3 4 5 6 7 X000001

MNOTICE

Fail to follow the DIP switch setting will cause the communication fault between battery and inverter, for more detail setting with different inverter/charger, please contact your supplier for consultation.

3.3.3.4RUN/ALM/SOC

Mode Status		RUN	ALM		LED indicator		Description		
Mode	Status	•	•	• • • •		Description			
Power off	-	OFF	OFF	OFF	OFF	OFF	OFF	All OFF	
Ot a seally se	Normal	FLASH1	OFF	A 1		4			
Standby	Warning	FLASH1	FLASH3	Accordi	ing to bat	tery SOC	,	See note	
	Normal	ON	OFF	According to battery SOC				Coo noto	
Charge	Warning	ON	FLASH3	(highest SOC LED: FLASH2)				See note	
	COCP	FLASH1	OFF	According to battery SOC Stop charging					
	Normal	FLASH3	OFF	According to battery SOC See note					
5	Warning	FLASH3	FLASH3				See note		
Discharge	CUVP/PUVP	OFF	FLASH3	OFF	OFF	OFF	OFF	Stop discharging	
	DOCP	OFF	ON	OFF	OFF	OFF	OFF	Stop discharging	
	CHTP/DHTP							Stop	
Temperature	CLTP/DLTP	OFF	ON	ON	OFF	OFF	OFF	OFF	charging/dischargin
	CLIT/DLIF							g	



	Cell/NTC							
	failure							
	Sensor							Stop
Failure	failure	OFF	ON	OFF	OFF	OFF	OFF	charging/dischargin
	MOS failure							g
	Reversed							
	polarity /SCP							

Note: 'Warning' including items of cell imbalanced/low voltage/high current/high&low temperature.

FLASH Type	ON	OFF
FLASH1	0.25\$	3.75\$
FLASH2	0.5\$	0.5\$
FLASH3	0.5\$	1.58

3.4 Protection function

Items	Description	Remark
Charge end	The BMS will stop charging if any cell or PACK voltage	Can Automatic recovery.
COVP	reach the protection value and it will be auto-released	
POVP	only when both Pack and cell voltage back to the release	
	voltage range or there is efficient discharge current.	
Discharge end	The BMS will stop discharging if any cell or PACK voltage	Can Automatic recovery. Please
CUVP	is under the protection value and it will be released only	charge timely, otherwise it may be
PUVP	when all the cell voltage back to the release voltage	in low-power mode to be over-
	range or there is efficient charge current.	discharged and damage battery.
CHTP	The BMS will stop charging or discharging or both if any	Automatic recovery when
DHTP	cell/environment/MOS temperature is beyond the range.	temperature falls.
CLTP	The BMS will stop charging or discharging or both if any	Automatic recovery when
DLTP	cell/environment/MOS temperature is under the range.	temperature rise.
COCP	The BMS will stop charging when the charging current is	Automatic recovery. If locked after
	higher than the protection value. And it will release from	three consecutive times, manual
	the protection when the system delays time is met.	intervention is required.
DOCP	The BMS will stop discharging when the discharging	Automatic recovery. If locked after
	current is higher than the protection value. And it will	three consecutive times, manual
	release from the protection when the system delays time	intervention is required.
	is met	
SCP	The BMS will stop charging when detect short circuit or	Charge to release.
Reversed	reversed polarity.	Manual press reset.
polarity		
Temperature,	Enter the failure mode, manual intervention is required no	Manual intervention.
Voltage,	charging and discharging.	
Current sensor		
failure		
Sleep mode	After reaching a certain condition, BMS will enter	Charge, press reset or restart to
	dormancy mode to reduce BMS consumption	activate.



A CAUTION

Please re-charge the battery via MPPT, grid/generator or other energy source within 24h if the battery is over discharged, otherwise, it may be damaged.

ANOTICE

Manually short-circuit and reverse the battery will void the warranty.



4 Installation

4.1 Preparation

4.1.1 Safety Compliance

The system installation must be finished by qualified person(s), During the whole installation process, please strictly follow the local safety regulations and related operating procedures.

4.1.2 Environment

The operating environment shall meet the following requirements:

Category	Description
Working	-10°C-50°C (Maximum operating range)
temperature	15℃-30℃ (Optimal temperature)
Relative humidity	5%~90%, No condensation
Altitude	<3000m
	Do not expose the battery to direct sunlight, rain and snow.
	•Do not place the battery within children/pet touchable area.
	Do not place the battery near heat source and flammable material
	•Do not drop, deform, impact, cut or spearing with a sharp object.
Safety requirement	Do not put heavy things on battery.
Salety requirement	Do not disassemble the battery without Manufacturer's permission.
	No conductive dust and water or other liquid to contact battery.
	•Follow the emergency measure if there is water invasion or electrolyte and gas
	leakage.
	Contact your supplier within 24 hours if any product failure happens.

4.1.3 Tools

Tools			
Torque screwdriver	Multi-meter	Flat-head screwdriver	Phillips-head screwdriver
Torque wrench	Cable crimper	Wire stripper	Drill
	Control of the contro		
Wire stripper	Tape measure	Phillips-screwdriver bit	Hex-key bit
\$ 0			




4.2 Inspection

4.2.1 Unpacking


- Please load and unload it in accordance with the specified requirements to prevent sun and rain when you receive the equipment.
- Please check and confirm the goods (such as quantity, appearance, etc.) according to the "scope of delivery " before unpacking.
- Do light take and put during unpacking process to protect the surface coating of the object;
- · Please record and feedback to the manufacturer if the inner packing is damaged after unpacking.

4.2.2 Scope of delivery


Check the scope of delivery for completeness and any externally visible damage. Contact your supplier for supplementary delivery if the listed material is incomplete or damaged.
















4.2.3 External cable kits

Cables connected to inverter or junction box belongs to an External Cable kits, NOT include in battery carton.

Customers need buy it separately, the information are as below.

Туре	Detail			Qty.		
	08.1	-2000±5				
Power cable	08,4	-2000±5				
Grounding cable		1pcs				
	8 Interest	-2000±15	lineatiet 1	1pcs		
		Battery side pin	Inverter side pin			
	Version I(CAN):	Pin 4	Pin 7			
Inverter communication		Pin 5	Pin 8			
cable(1 out of 3)		Pin 6	Pin 3			
	Version II(CAN):	Pin 4	Pin 4	1		
		Pin 5	Pin 5			
	Version III(RS485):	Pin 1	Pin 3	1		
		Pin 2	Pin 5			



For inverter communication PIN definition detail, please check Appendix I



Keep the unused cable pins NULL to avoid affecting the closed loop communication.

A NOTICE

A ground connection of communication cable may be required from some inverters, please follow the rules from inverter manufacture.

4.2.4 Battery registration

We strongly recommend you to register battery to achieve extended warranty, please scan the QR code below to fulfill the correct information of your product and configuration.



4.3 Start Installation



4.3.1 Remainder

Please check again the following conditions or equipment whether meet the requirements before installation:

- Check if there's enough space for installation, and if the load-bearing capacity of the bracket or cabinet meets the weight requirements.
- Check whether the power cable pair(s) used meets the maximum current requirement for operation.
- Check whether the overall layout of power supply equipment and batteries at the construction site is reasonable.
- Check whether the installer is wearing anti-static wristband.
- Check whether there're two people on the construction site for installation work.
- Check if there's potential risks at location of installation site, e.g flooding, sun exposure, corrosion, and salt spray.

4.3.2 Procedures



Injuries may result if the product is lifted incorrectly or dropped while being transported or mounted. Wear suitable personal protective equipment for all work on the product.



A CAUTION

Ensure that no lines are laid in the wall which could be damaged when drilling holes.

4.3.2.1 Rack mounted

- i. Take the battery pack out from carton.
- ii. Get the Rack or cabinet ready and place it horizontally at a reasonable location.
- iii. Place the battery on the rack or cabinet tray via manual-lift, Insert the screws and fasten the battery to the rack or cabinet.
- iv. Finish the cable connection

4.3.2.2 Stack mounted

i. Take the battery pack out from carton.	
ii. Remove the mounting ear from both side of the battery.	
iii. Install the stacking component at four corners of the battery.	
iv. Remove the hook on the stacking component of the bottom battery of each stack.	
v. Put another battery on top of the previous module, and align the locating holes and connect the 4 lockers together.	3 4 3
vi. The maximum number in each stack is 4 modules. vii. Finish the cable connection	

Note: Do not stack the batteries directly.

4.3.2.3 Wall mounted



i. Take the battery pack out from carton.	
ii. Remove the mounting ear from both side of the battery, and separate the wall mounting bracket and widget.	10 A
, g	
iii. Take out the wall mounting bracket, place it onto the wall	
horizontally and mark the hole position on the panel. iv. Drill holes in the wall for the M10 expansion bolt. The drilling	
depth should be at least 60 mm, insert the bolt.	
v. Fix the bracket with the nut	
vi. Fix the wall mounting widget and the decorative panel with	
the battery using the combination screw	
vii. Lift the battery up and put the hook into the bracket hanging	
hole, fix the widget with the bracket via the combination screw and tighten it using a screwdriver	
and lighternit using a screwdriver	
viii. Finish the cable connection	

A CAUTION

Please fix the parallel cable between batteries with the wall or other part to avoid enduring the gravity of conductor for long time.

4.3.2.4 Floor mounted


i. Take the battery pack out from carton.	
ii. Remove the mounting ear from both side of the battery.	



iii. Place the base near the wall, align with the wall and make sure the distance is between 10mm and 35mm. iv. Drill holes on the ground for the M6 expansion bolt. The drilling depth should be at least 50 mm, insert the bolt. (this step is optional) v. Fix the base with nut. (this step is optional)	10~35mm
vi. Fix the decorative panel and wall hang ear with the battery using the combination screw, and place the battery onto the base. vii. Adjust the position of the hang ear, make sure they can connect wall smoothly, mark the hole position of both hang ear.	
viii. Remove hang ear from the battery, and drill holes in the wall for the M6 expansion bolt. The drilling depth should be at least 50 mm, insert the bolt. ix. Fix the hang ear with battery and fasten the bolt with nut.	
i. Finish the cable connection	


4.3.3 Tips

4.3.3.1 Installation not allowed





4.3.3.2 Other Installation





ANY others installations, please avoid the battery directly contacting the ground and avoid of high salinity, humidity to prevent the product from rusting and corrosion.



5. Cable connection and commissioning




5.1 Get battery ready

- 5.1.1 Ensure all the battery is in OFF mode, check and confirm the installation is tighten and stable.
- 5.1.2 Check the number and specification of cable kit accessories are correct according to the Scope of delivery item, if you are making cable yourself, please follow manufacturer's requirements.
- 5.1.3 Switch on all battery individually before wiring, check whether there is any alarm/protection information, if yes, turns to troubleshooting. Then switch off all batteries.


5.2 Grounding cable connection

- 5.2.1 Take out the grounding screw on the battery panel, and get the cable conductor through it.
- 5.2.2 Fix them together, with a cylinder screwdriver and tighten it.
- 5.2.3 Connect the grounding cable with next battery module.



5.3 Communication cable connection

- 5.3.1 Take out battery to battery communication cable.
- 5.3.2 Confirm the location of Master battery, insert the RJ45 plug into the Link Out port and connect the other side to next battery Link IN port, daisy chained all batteries.






Note: the module with empty Link IN port is Master battery

A NOTICE

The BMS inside the battery pack will automatically terminate BOTH end of CANBUS pins, DO NOT need to plug the 120Ω terminator again.

5.4 DC power cable connection

- 5.4.1 Take out battery to battery power parallel cable.
- 5.4.2 Insert the Plug into the power socket until you hear the 'click' sound.



5.5 Connecting with inverter

A CAUTION

Confirm inverter AC input and PV input is disconnected before wiring connection, and the DC/ signal switch of inverter/charger is in off status.

- 5.5.1 Connecting Master battery Link IN port with inverter CAN or RS485 communication port via inverter communication cable (Version I/II/III or customized).
- 5.5.2 Connecting battery OUTPUT (+) with inverter battery INPUT (+), battery OUTPUT (-) with inverter battery INPUT (-), an external disconnection breaker between battery system and inverter is recommended, choose the corresponding power cable pair and wiring them correctly.


Note:


ANOTICE


Choose the suitable disconnection breaker considering the inverter power/current, rated voltage, tripping characteristic etc.




Wiring diagram allowed:







Wiring diagram not allowed:






ANOTICE

The maximum communication cable length is required to be less than 15m between inverter/charge and battery. The maximum power cable length is suggested to be less than 10m between inverter/charge and battery.

For Australia market:

In order to meet the AS/NZS 5139:2019 installation standard, a battery disconnection breaker is a mandatory between each battery module and inverter, please choose appropriate breaker following the standard.



For other type of installation, please also follow the rules above to wiring your system.

A CAUTION

The maximum tolerance current of each power cable and terminal is 125A, 100A for continuously is suggested, please use corresponding number of power cable pairs according to the field configuration and local connection requirements, standards, and directives.

5.6 Commissioning

- 5.6.1 Set the DIP address of the Master battery (and the Slave battery if there is any RS485 baud rate changed).
- 5.6.2 Switch on all battery modules, wait for 10s, make sure that only M/S led is on Master battery.
- 5.6.3 Turn on the breaker between the inverter and battery if there is any, then turn on the inverter/charger isolator.
- 5.6.4 Finish the setting on inverter/charger or any other control devices, if everything is correct, you are ready to use the system.

No.	Inverter setting parameters	Detail
1	Absorption voltage	56.0V



2	Float voltage	54.6V
3	Re-charge/Generator start voltage	≥50V
4	Re-start voltage	52V
3	Low SOC limit (Grid-tied)	10/20% (differ from inverter brand)
5	Low SOC cut-off	4%
6	Low Voltage cut-off	48.0V
7	Rated charging current limited value	50A*N (N is the Quantity of the battery pack)
8	Rated discharging current limited value	50A*N (N is the Quantity of the battery pack)
9	Max. charging current limited value	70A*N (N is the Quantity of the battery pack)
10	Max. discharging current limited value	100A*N (N is the Quantity of the battery pack)
11	Force charge	Enable

For more information to connect with different inverter/charger, please contact your supplier for technical support.



If your system is a back-up or off-grid system, make sure your configuration can cover the worst situation to avoid battery to be over-discharged.

5.7 Switch off battery

- 5.7.1 Turn off the inverter.
- 5.7.2 Turn off the disconnection breaker if there is any.
- 5.7.3 Turn off all batteries signal switch.



5. Troubleshooting and FAQ

Items	Solution	Measure
	Power on battery and press RESET 6s to observe whether the	
Unable to start	battery can be started.	
Onable to start	2. Charge the battery use a charger or inverter to provide 54~57.6V	
	voltage and observe it can be started.	
	Check whether the cable connection between the battery and the	
Unable to	inverter/charger is correct.	
	Check whether the inverter/charger setting is correct.	
charge	3. Check whether the battery is in charge protection mode, if yes, try	If the abnormal
	to discharge the battery.	status still alive after
	Check whether the cable connection between the battery and the	above steps, please
	inverter/charger is correct	contact your
Unable to	2. Check whether the battery occurs short circuit, reverse connection,	supplier.
discharge	pre-charge failure during connection inverter etc.	
	3. Check whether the battery is in discharge protection mode, if yes, try	If there is any other
	to charge the battery.	situation(s)
High/Low	1. Stop the battery system for a while, check whether the installation	excluding in this
	location temperature meet the requirement.	table, turn off the
temperature	Avoid continuous full charging and discharging.	fault battery, contact
High ourront	Check the configuration and parameters setting on the inverter/charger	your supplier.
High current	is correct.	
ALM always	Check the fault information on the inverter APP or display if possible.	
on		
	Check the communication cable type is correct and is contacted well.	
Communicatio	Check the DIP switch setting is correct.	
n fail	Check the inverter protocol related setting is correct.	
	4. Check both battery and inverter are working properly.	

Q1: Battery maximum SOC is 99% and never goes to 100%SOC during daily cycle use, why?

Generally, there is no effect to system on this point. BMS will calibrate the SOC to 100% when reached cut-off current or trigger CHVP, however, to avoid battery from being overcharged and to extend the cycle life as longer as possible, we left a room and set a charging profile to let battery not be charged at high voltage near full. Keep float the battery for approximately 0.5~1 hour to calibrate.

Q2: 'High voltage' and 'cell unbalance' warning and alarm in rare cases, does it mean battery is damaged?

No. This is not unusual and happened on new batteries that are not balanced yet, please lower the maximum charge voltage (54.6V) and float the battery via grid or generator. If not solved, please contact your supplier.

Q3: When having multiple batteries in parallel connection, the battery on the end can't be fully charged.

Pay attention to your wiring diagram, please always follow the manual wiring advises and choose proper cable size and pair.



Q4: The current is 0A when connecting with a very small load at the situation that having multiple batteries in parallel connection, how to solve it?

Each BMS has a threshold current of 0.5A (~25W) before it begins to report, this leads the inaccurate display of the current.

Q5: SOC suddenly jump to 100% during charging.

This is normal in off-grid application and usually happened on batteries that not been calibrated SOC for long time, we suggest to fully charge the batteries per month.

6. Transport, Storage


- Do not violently shake, impact or squeeze, and prevent sun and rain during the transportation.
- Do light take and put and strictly prevent falling, rolling, and heavy pressure during loading and unloading.
- The battery should be placed in a dry, clean, dark, and well-ventilated indoor environment for long-term storage, and the recommended storage temperature range is $15\sim30$ °C.
- No harmful gases, flammable and explosive products and corrosive chemical substances in the storage location.
- The batteries should be stored and transported in close to 50% SOC, do not store over 80%SOC for long time.
- If do not use for a long time, the battery needs to be charged every 6 months.
- No fall down, no pile up over 6 layers, and keep face up.

7. Disposal of battery

Disposal of battery must comply with the local applicable disposal regulations for electronic waste and used batteries, please review your local Battery recycling or management regulations or contact your supplier for more information.


Appendix I

Connect with Victron GX & inverter/charger



Battery Link IN port	Victron VE.CAN/BMS CAN	Cable suggest
Pin4	Pin7	Version-I(CAN)
Pin5	Pin8	
Pin6	Pin3	


Connect with SMA inverter/charger



Battery Link IN port	SMA sunny island	Cable suggest
Pin4	Pin4	Version-II(CAN)
Pin5	Pin5	
Pin6 (optional)	Pin2 (optional)	




Connect with Schneider inverter/charger




Battery Link IN port	Conext Gateway	Cable suggest
Pin4	Pin14	customized
Pin5	Pin12	
Pin6 (optional)	Pin10 (optional)	

Connect with Studer inverter/charger




Battery Link IN port	X-Com CAN	Cable suggest
Pin4	Pin4	Version-II(CAN)
Pin5	Pin5	

Connect with GOODWE hybrid inverter




Battery Link IN port	GOODWE BMS CAN	Cable suggest
Pin4	Pin4	Version-II(CAN)
Pin5	Pin5	

Connect with Sol-Ark hybrid inverter




Battery Link IN port	Sol-Ark CAN	Cable suggest
Pin4	Pin4	Version-II(CAN)
Pin5	Pin5	
Pin6 (optional)	Pin6 -outdoor Pin2 -indoor (optional)	

Connect with Growatt inverter



Battery Link IN port	Growatt BMS communication port	Cable suggest
Pin4	Pin4	Version-II(CAN)
Pin5	Pin5	


Connect with Solis inverter



Battery Link IN port	Solis CAN	Cable suggest
Pin4	Pin4	Version-II(CAN)
Pin5	Pin5	




Connect with Deye hybrid inverter




Battery Link IN port	Deye CAN	Cable suggest
Pin4	Pin4	Version-II(CAN)
Pin5	Pin5	

Connect with SUNSYNK hybrid inverter




Battery Link IN port	Sunsynk CAN	Cable suggest
Pin4	Pin4	Version-II(CAN)
Pin5	Pin5	

Connect with SAJ hybrid inverter




Battery Link IN port	SAJ CAN	Cable suggest
Pin4	Pin4	Version-II(CAN)
Pin5	Pin5	

Connect with LUXPOWER inverter




Battery Link IN port	LUXPOWER CAN	Cable suggest
Pin4	Pin4	customized
Pin5	Pin3	

Connect with Megarevo/INVT inverter



Battery Link IN port	Megarevo CAN	Cable suggest
Pin4	Pin4	Version-II(CAN)
Pin5	Pin5	


Connect with MUST inverter



Battery Link IN port	MUST CAN	Cable suggest
Pin4	Pin6	customized
Pin5	Pin5	




Connect with Alpha & Outback energy inverter




Battery Link IN port	Alpha&Outback BMS communication	Cable suggest
Pin1	Pin3	Version-III(RS485)
Pin2	Pin5]

Connect with Voltronic inverter




Battery Link IN port	Voltronic BMS communication	Cable suggest
Pin1	Pin3	Version-III(RS485)
Pin2	Pin5	

Connect with Phocos inverter



Battery Link IN port	Phocos BMS communication	Cable suggest
Pin1	Pin3	Version-III(RS485)
Pin2	Pin5	

Connect with Mpp solar inverter



Battery Link IN port	communication	Cable suggest
Pin1	Pin3	Version-III(RS485)
Pin2	Pin5	

TOPBAND BATTERY

SHENZHEN TOPBAND BATTERY Co., Ltd

Address: TOPBAND Industrial Park, Liyuan Industrial Zone, Shiyan, Bao'an, Shenzhen, China

Postcode: 518108

Tel: +86-755 2765 1888 Fax: +86-755 8178 5047

Web: www.topbandbattery.com